

Have the Coolest Sled on the Snow!



Alan & Tammy Schoen
361 SE Sunrise Drive
Mountain Home, ID 83647

208-587-8584
www.2coolairvents.com
info@2coolairvents.com

Installation Instructions on back



We suggest removing the sticker on your hood as it looks better through the vent. A blow dryer or heat gun works great.

Lay the hood vent on the hood and mark the rivet holes. Choose your hole size(s) and drill inside the rivet holes in whatever pattern you choose.

Pop rivet the hood in place starting in the center to keep it aligned.



Enjoy your new vent!